

A range of products designed for the control and monitoring of emergency exit panic bars

ExitPanicbarAlarm

This battery operated unit offers a high visual deterrence to misuse of panic bars and is simple to install on all types of door. The device is either screwed or glued, using special adhesive strips, onto the door leaf.

The trigger angle is attached to the alarm unit with a red fixing clip and extended until is located underneath the panic bar. When the panic bar is pushed the red fixing clip breaks off and an 85dB/1m acoustic alarm is activated. Only authorised personnel can switch off the unit using a key. It is reactivated by fitting a new red fixing clip.



A pre-alarm warns against unauthorised use as soon as the panic bar is depressed slightly and stops if the panic bar is released

Each Unit includes a battery monitoring system which gives an audible indication when the battery is low

6 replacement upper fixing clips are also included with each kit.

Optional radio transmission allows the signal to be relayed to a monitoring area

ExitDoorShield for Panic Bars

Also available for use on emergency doors, in accordance with EN1179 is the, ExitDoorShield with panic bar adapter (see separate datasheet) a sturdy metal unit which can be

